

AROMA®

Juice Extractor



Instruction Manual & Juice Recipes

Model: ACJ-260

IMPORTANT SAFEGUARDS

1. Read all instructions before operating.
2. To protect against risk of electrical shock, do not immerse power cord, plug or the product in water or other liquid.
3. Close supervision is necessary when the juice extractor is used by or near children.
4. Unplug from outlet when not in use, before putting on or taking off parts and before cleaning.
5. Do not operate the juice extractor with a damaged cord or plug or after the juice extractor malfunctions, is dropped or damaged in any manner. Return the appliance to the nearest authorized service facility for examination, repair or electrical or mechanical adjustment.
6. The use of attachments not recommended or sold by the manufacturer may cause fire, electric shock or injury.
7. Do not use outdoors.
8. Do not let cord hang over edge of table or counter.
9. Be sure to turn switch to OFF position after each use of the juice extractor.
10. Avoid contacting any moving parts.
11. Do not feed food by hand; always use food plunger when extracting juice.
12. Always make sure the cutter/strainer and top protective cover fit securely in place before the juice extractor is turned ON. Do not unfasten or unlock the safety cover lock while the product is in operation.
13. Cutting teeth of cutter/ strainer are sharp. Use extra caution when handling it.
14. Do not put fingers or objects other than fruit and vegetables into the juice extractor while it is in operation. If food becomes lodged in opening, use food plunger or another piece of fruit or vegetable to push it down. When necessary, turn the extractor OFF and remove the remaining food inside the extractor.
15. Use this product with rated 110 voltage A.C. outlet only.

This appliance is intended for Household Use Only.

SAVE THESE INSTRUCTIONS

SHORT CORD INSTRUCTIONS

1. A short detachable power-supply cord is provided to reduce risks resulting from becoming entangled in or tripping over a longer cord.
2. Longer detachable power-supply cords or extension cords are available and may be used if care is exercised in their use.
3. If a longer detachable power-supply cord or extension cord is used:
 - a. The marked electrical rating of the extension cord should be at least as great as the electrical rating of the appliance.
 - b. The longer cord should be arranged so that it will not drape over the counter top or tabletop where it can be pulled on by children or tripped over unintentionally, the extension cord should be a grounding-type 3-wire cord.

POLARIZED PLUG

If this appliance has a **polarized plug** (one blade is wider than the other), follow the instructions below:

To reduce the risk of electric shock, this plug is intended to fit into a polarized outlet only one way. If the plug does not fit fully into the outlet, reverse the plug.

If it still does not fit, contact a qualified electrician. Do not attempt to modify the plug in any way.

PARTS IDENTIFICATION

1. Plunger
2. Feeding channel
3. Protective cover
4. Cutter/Strainer
5. Separating unit
6. Juice Spout
7. Residue Spout
8. Motor Unit
9. Pulp container
10. Cover safety latches
11. ON / OFF Switch
12. Juice container
13. Cup drip tray

HOW TO USE

BEFORE USING FOR THE FIRST TIME

1. Check that whether the voltage of the juice extractor corresponds to the voltage on your main supply meter.
2. Wash the parts of the product, which will come into contact with food.
3. Practice assembling and disassembling the juice extractor a few times before starting to use it.

DISASSEMBLE AND ASSEMBLE THE JUICE EXTRACTOR

(Please refer the parts to the number indicated in Parts and Identification page)

⊕ Disassemble

1. Turn the switch to OFF position. Unfasten the cover latches. Remove the top cover and the separating unit.
2. Gently remove the cutter/strainer upwards from separating unit.
3. Remove the separating unit from the motor base.

⊕ Assemble

4. Place the separating unit on motor base, use both hands and make sure the unit fits in place. Gently insert cutter/strainer onto the separating unit, turn it clockwise and make sure it sits securely and balanced on the separating unit and the motor base. **IMPORTANT:** The cutter must be placed securely on the separating unit and motor base in order to make the juice extractor function properly.
5. Place the protective cover on top of the juice extractor and fasten the safety latches on BOTH SIDES.
6. Place the pulp container under the residue spout.
7. Place the juice collector under the juice spout.
8. Plug in the juice extractor and you are ready to use the juice extractor.

CAUTION:

The product is equipped with a safety protection system. If the protective cover is not corrected placed or the cover latches are unfastened, the juice extractor will not start to function.

START EXTRACTING JUICE

1. Rinse and clean vegetables and fruits thoroughly first. Peel and remove core if needed. Cut food into small pieces for fitting into the feeding channel of the protective cover. (We suggest to cut food no bigger than 2" long and ¾" wide; slightly adjust the size of food for it to fit the channel.)
2. Turn switch to ON position. Use food plunger to press down fruits and vegetables GENTLY into juice extractor. Process soft-textured fruits first (such as melon and peach), followed by firmer fruits and vegetables (such as carrots and celery). IMPORTANT: Do not force the food into the cutter/strainer, instead, use firm but moderate pressure.
3. Use juice collector to collect juice.
4. To empty the pulp container: turn juice extractor to OFF position. Use handle to remove the pulp collector and discard the pulp. Rinse the container with water and put it back to the place. For best results, empty pulp container when it is ¾ filled.



JUICING TIPS

- Hand form leafy vegetables such as spinach and parsley into compact (ball) shapes first, and feed into the feeding channel.
- Always serve juice immediately. The vitamin content of juice decreases when juices are stored. If necessary, cover the juice container tightly with food wraps and store it in refrigerator. Do not store over 24 hours.
- Add a few spoonfuls of lemon juice in your juice collector before juicing to keep juices from discoloring.
- When preparing large quantity of fruits and vegetables to make juice, check pulp container after processing 2 lbs. of food.
- Do not use this juice extractor to extract juices from avocado, banana and raspberries.
- Use layers of cheesecloth to filter juice if clear juice is desired.
- When processing moist, leafy vegetables or extract a large amount of fruits and vegetables, the area between the cutter/strainer and the separating unit may become clogged. If the juice extractor becomes clogged or vibrates excessively, turn the unit to OFF position, unplug cord and allow the cutter/strainer to stop completely. Empty the pulp completely and replace cover and fasten the cover latches. It is now ready to continue to process juice.

IMPORTANT NOTE:

- Always make sure that the cutter/strainer is securely placed on the separating unit and the motor base in order to have the juice extractor function properly.
- Some pulp remaining in juice is normal, which increases the nutritive value of the juice.

CAUTION:

- Always use food plunger to feed food into feeding channel.
- Do not touch any moving parts of the juice extractor while in use.
- Unplug before assembling, cleaning and removing parts.
- Turn off the juice extractor and unplug when having any clogging problems. Remove pulp on the cutter/ strainer or in the clogged area and continue to use the product.

HOW TO CLEAN

BEFORE CLEANING, TURN THE SWITCH TO "OFF" AND UNPLUG.

1. Gently Remove the protective cover, the separating unit and the cutter/strainer from the juice extractor.
2. Also empty all pulps in the pulp container and inside the protective cover and use water to rinse both parts.
3. Clean the cutter/strainer by rinsing with water by using a small brush to remove the remaining pulp. Note: Use a soft brush to brush clean the cutter/strainer. Do not use metal brushes or metal scouring pad for cleaning.
4. For cleaning the exterior of the motor base, use a damp sponge and wipe dry with dry dishcloth.
5. Never immerse the motor base in water or any liquid.

CAUTION:

- Do not clean the cutter/strainer in dishwasher.
- Do not use bleach for cleaning.
- The cutter/strainer **must be replaced** as soon as possible when there is sign of damage and wear.



FOR ORDERING PARTS OR
IF YOU HAVE ANY COMMENTS ABOUT THIS PRODUCT,
PLEASE CONTACT AROMA CUSTOMER SERVICE DEPARTMENT
AT 1-800-276-6286

JUICE RECIPES



Please see *How To Use* in page 4 and 5 for user instructions

Healthy, Delicious Juice	Easy HOW TO
<p>AAA Juice 6 carrots 2 stalks of celery 1 apple 1/2 handful of wheatgrass 1/2 handful of parsley 1/2 beet</p>	<p>Rinse all ingredients with water. Remove core of apple. Cut apple and beet into the size that fit the feeding channel.</p>
<p>Creamy Sensation 1 peeled orange 1/2 apple 1/4 tsp. Honey 1/4 tsp. Vanilla extract 2 tbsp. Non-fat dehydrated milk</p>	<p>Remove core of apple. Cut apple and orange into the size that fit the feeding channel. After juice is extracted, use shaker to shake juice, honey, dry milk and vanilla extract and serve.</p>
<p>Cantaloupe Delight 1/4 ginger root 5 medium carrots, no green 1 apple</p>	<p>Rinse ginger and carrot with water. Cut ingredients into the size that fit the feeding channel of extractor and extract juice.</p>
<p>Golden Aroma 1 mango 2 carrots, no greens 1 green apple 4 peeled oranges 6 strawberries</p>	<p>Peel mangle and oranges. Rinse apple and strawberries with water. Remove core of apple and mango. Cut apple and mango into size that fit the feeding channel and extract juice.</p>
<p>Health Combo Handful of Spinach Handful of Parsley 4 carrots 2 celery stalks</p>	<p>Rinse spinach thoroughly with water, make sure not dirt left on leaves. Shape spinach and parsley leaves in ball shape to fit the feeding channel, and extract juice.</p>
<p>Body Cleanser 4 carrots 2 cucumber 1 beet</p>	<p>Cut beet and cucumber into the size that can fit into the feeding channel and extract juice.</p>

Healthy, Delicious Juice	Easy HOW TO
<p>Protein Boost 1/4 pineapple, peeled 1 peeled banana 1/2 cup soymilk 3 tbsp. Protein powder</p>	<p>Peel pineapple and banana. Cut into the size that can fit the feeding channel and extract juice. Use milk shake bottle to shake the juice, soymilk and protein powder for 20 seconds and serve.</p>
<p>Spring Aroma 8 oz. Plain Yogurt 5 strawberries 10 frozen grapes 1/2 frozen banana, peeled 3 oranges, peeled</p>	<p>Rinse strawberries with water and peel oranges. Cut oranges in the size that can fit into the feeding channel and extract juice. Use shaker to shake the juice and yogurt for 30 seconds and serve.</p>
<p>Body Balancer 3 carrots 2 lettuce leaves 1 handful string beans 4 Brussels sprouts 2 apples</p>	<p>Rinse all ingredients with water. Remove core of apple. Cut Brussels sprouts in half to fit the feeding channel. Fold lettuce into ball shape to fit the feeding channel. Extract juice and serve.</p>
<p>Tomato Pasture 1 1/2 large tomato 1/2 lemon 2 stalks of celery 1 1/2 cups of cold buttermilk Few ice cubes</p>	<p>Rinse tomatoes, lemon and celery with water. Extract juice. Use shaker to shake juice, butter milk with ice seconds and serve.</p>
<p>Veggie Snap 4 carrots 4 asparagus spears Handful of spinach 5 leaves of lettuce</p>	<p>Rinse all ingredients with water. Make sure no dirt left on spinach leaves and roots. Fold spinach leaves and lettuce into ball shape and extract juice.</p>
<p>Liver Reliever 4 medium potatoes few ice cubes</p>	<p>Rinse potatoes with water and peel. Cut them into the size that can fit the feeding channel. Extract juice and serve with adding ice cubes.</p>
<p>Pearful Delight 3 Asian pears 1/2 tsp. honey 1 white peach</p>	<p>Rinse pears and peach with water and peel. Cut them into the size that can fit the feeding channel. Extract juice and stir in honey before serving.</p>

LIMITED WARRANTY

Aroma Housewares Company warrants this product free from defects in material and workmanship for one year from provable date of purchase.

Within this warranty period, Aroma Housewares Company will repair or replace, at its option, defective parts at no charge, provided the product is returned, freight prepaid with proof of purchase and U.S. \$6.00 for shipping and handling charges to Aroma Housewares Company. Please call the toll free number below for return authorization number. Allow 2-4 weeks for return shipping.

This warranty does not cover improper installation, misuse, abuse or neglect on part of the owner. Warranty is also invalid in any case that the product is taken apart or serviced by an unauthorized service station.

This warranty gives you specific legal rights and they may vary from state to state.

AROMA HOUSEWARES COMPANY
6469 Flanders Drive
San Diego, California 92121
1-800-276-6286
M-F, 8:30 AM - 5:00 PM, Pacific Time

