

# AROMA® Electric Kettle

PROFESSIONAL™



**Questions or concerns about your electric kettle?**  
*Before returning to the store...*



*Aroma's customer service experts are happy to help.*  
**Call us toll-free at 1-800-276-6286**



*Answers to many common questions and even replacement parts can be found online. Visit*  
**[www.AromaCo.com/Support](http://www.AromaCo.com/Support).**

Congratulations on your purchase of the Aroma® Professional™ Electric Kettle. This handy appliance provides more speed and convenience than traditional stovetop kettles, not to mention the increased safety features! The compact, cordless body is finished in stainless steel and made to blend seamlessly and stylishly into your kitchen.

This product was designed with your safety in mind. Features such as cordless pouring and the 360° swivel base, which allows left or right-handed gripping, are designed to remove many of the dangers and inconveniences associated with other kettles. Additional safety features include the stay-cool handles and base, drip-free pouring spout and automatic-shut off with boil dry protection. Gone are the days when forgotten kettles caused steam damage to cabinets or posed risks by boiling dry. The Aroma® Electric Kettle turns off automatically once the water has boiled and will not operate when empty.

For more information on your Aroma® Electric Kettle, or for product service and other home appliance solutions, please visit us online at [www.AromaCo.com](http://www.AromaCo.com).

**See what's cooking with Aroma® online!**



[www.AromaTestKitchen.com](http://www.AromaTestKitchen.com)



[www.facebook.com/AromaHousewares](http://www.facebook.com/AromaHousewares)



[www.pinterest.com/aromahousewares](http://www.pinterest.com/aromahousewares)



[www.twitter.com/AromaHousewares](http://www.twitter.com/AromaHousewares)



[www.instagram.com/AromaHousewares](http://www.instagram.com/AromaHousewares)

Published By:  
Aroma Housewares Co.  
6469 Flanders Drive  
San Diego, CA 92121  
U.S.A.  
1-800-276-6286  
[www.AromaCo.com](http://www.AromaCo.com)  
©2014 Aroma Housewares Company  
All rights reserved.



# IMPORTANT SAFEGUARDS

**WARNING:** *Serious personal injuries can occur with any kettle if it is not used properly. To avoid such risks, always follow the following basic safety precautions:*


- 1. Read all instructions before using the appliance.**
2. Do not touch hot surfaces. Use handles or knobs. Metal surfaces become extremely hot.
3. To prevent against electrical hazards, do not immerse cord, plug or kettle in water or any other liquid. See instructions for cleaning.
4. Close supervision is necessary when the appliance is used by or near children.
5. Always unplug the appliance from the outlet when not in use and before cleaning. Allow unit to cool completely before cleaning and handling.
6. Do not operate appliance with a damaged cord or plug, or after appliance malfunctions or has been damaged in any manner. Contact Aroma® customer service for examination, repair or electrical/mechanical adjustment.
7. The use of accessory attachments not recommended by Aroma® Housewares may cause injuries.
8. Do not use outdoors.
9. Do not allow cord to hang over the edge of the table or counter or to touch hot surfaces.
10. Do not place kettle on or near a hot gas or electric burner or in a heated oven.
11. To disconnect, turn any control to the "OFF" position, then remove the plug. Never unplug by pulling on the cord.
12. Do not use kettle for anything other than its intended use.
13. The power base must only be used with the provided kettle.
14. Only use the kettle to heat water. No other liquids should be placed inside the kettle.
15. Do not unscrew any screws on the kettle or power base or attempt to disassemble them in any way.
16. Do not move kettle during the heating process.
17. Do not immerse this appliance or any of its parts in water.
18. Scalding may occur if the lid is removed during the boiling cycle.
- 19. Caution: If water exceeds the "MAX" line, the boiled water may spill out during the boiling process.**



# IMPORTANT SAFEGUARDS


## Short Cord Instructions

1. A short power-supply cord is provided to reduce the risks resulting from becoming entangled in or tripping over a longer cord.
2. Longer extension cords are available and may be used if care is exercised in their use.
3. If a longer extension cord is used:
  - a. The marked electrical rating of the extension cord should be at least as great as the electrical rating of the appliance.
  - b. The longer cord should be arranged so that it will not drape over the counter top or tabletop where it can be pulled by children or tripped over unintentionally.
  - c. If the appliance is of the grounded type, the extension cord should be a grounding 3-wire cord.




## Grounding Instructions

This appliance must be grounded while in use to protect the operator from electrical shock. The appliance is equipped with a 3-conductor cord and a 3-prong grounding-type plug to fit the proper grounding-type receptacle. The appliance has a plug that looks like sketch A. An adapter, sketch B, should be used for connecting sketch-A plugs to two-prong receptacles. The grounding tab, which extends from the adapter, must be connected to a permanent ground such as a properly grounded outlet box as shown in sketch C using a metal screw.





# PARTS AND FEATURES





# BEFORE FIRST USE

*Before using for the first time, it is recommended to clean the interior of the kettle thoroughly. Please follow the procedure below before using the kettle*

1. Remove all packing materials and make sure that the product is received in good condition.
2. Taking care to keep the electrical components on the exterior of the kettle dry, wipe out the interior of the kettle with a damp, soapy cloth.



- If your hand will not fit inside the kettle, swish warm, soapy water around the inside of the kettle with the lid closed. Rinse thoroughly with water.

3. Rinse out the inside of the kettle thoroughly with water.
4. With a damp cloth, gently wipe off the exterior of the kettle. Do not wipe off electrical components.
5. Dry all parts completely.
6. It is also recommended to run your kettle through one boiling cycle before using it to consume beverages. Following the instructions in “Boiling Water” on page 5, boil one kettle of water. When water has boiled, pour it out and rinse the inside of the kettle once more.
7. Your kettle is now ready for use.



# TO BOIL WATER

1. Place the power base on a sturdy, level and heat-resistant surface.
2. Remove the lid and fill with water through lid opening. Fill between the “MIN” and “MAX” line on the Water Level Indicator.



## HELPFUL HINT

- Use distilled water when possible for best taste and to minimize mineral build-up in the kettle.

3. Replace the lid so that it snaps securely into place.
4. Place the kettle onto the power base and plug the power cord into an available electrical outlet.
5. Push down on the POWER SWITCH to begin the boiling process. The indicator light will illuminate.



## NOTE

- Never fill kettle with any liquid other than water.
- Never open the lid while water is boiling.
- The stainless steel body will become extremely hot.

6. Once the water has boiled, the power switch will flip up with an audible click. The indicator light will turn off, and the kettle will automatically shut off.
7. Lift the kettle off the power base before pouring, using the easy-grip handle. Take care not to touch the stainless steel body, as it will be hot.
8. After pouring, make sure the bottom of the kettle and the power base are dry before placing kettle on the power base.
9. When not in use, unplug the power base from the electrical outlet.



# TO CLEAN

1. Always unplug the electric kettle and allow it to cool completely before cleaning.
2. Wipe the exterior of the kettle with a clean, damp cloth, taking care to avoid electrical components. Use a soft cloth to dry.
3. To clean the interior of the kettle, use a soft sponge and soapy water to gently scrub.



## HELPFUL HINT

- If your hand will not fit inside the kettle, swish warm, soapy water around the inside of the kettle with the lid closed. Rinse thoroughly with water.



## CAUTION

- Never attempt to disassemble the kettle or power base.
- Never immerse the kettle, cord, plug or power base in water. Always take care not to allow electrical components to come into contact with water.
- Do not use abrasive cleaners or scouring pads of any kind on the kettle or power base. This will cause damage to the finish and may create a risk of electric shock.



# REMOVING MINERAL DEPOSITS

*Before using for the first time, it is recommended to clean the interior of the kettle thoroughly. Please follow the procedure below before using the kettle*

1. Fill the kettle halfway with water and bring to a boil.
2. Add one cup of white vinegar. Let the mixture soak overnight or for at least 6 hours.
3. Empty the mixture and rinse out the kettle.
4. Refill the kettle with water only. Bring to a boil and empty again.
5. Repeat as needed.



# TROUBLESHOOTING

<p><b>The kettle and indicator light do not work when the power switch is up.</b></p>	<ul style="list-style-type: none"><li>• Make sure the kettle is seated properly on the power base and that the base is connected to a functioning electrical outlet.</li><li>• If the problem persists, please contact our customer service department toll-free at 1-800-276-6286 or through email at CustomerService@AromaCo.com.</li></ul>
<p><b>The water is boiling, but the power switch and indicator light do not turn off.</b></p>	<ul style="list-style-type: none"><li>• The auto-shut off function will not operate properly if the lid is not completely closed. Allow kettle to cool, then check to see that the the lid is properly locked into place.</li><li>• If the problem persists, please contact our customer service department toll-free at 1-800-276-6286 or through email at CustomerService@AromaCo.com.</li></ul>
<p><b>The power switch will not stay down and the kettle will not turn on.</b></p>	<ul style="list-style-type: none"><li>• Make sure that the kettle is seated properly on the power base and that the base is connected to a functioning electrical outlet.</li><li>• Water or debris on the bottom of the kettle or on the power base may interfere with the functioning of the kettle. Be sure that the base of the kettle and the power base are dry and free of debris.</li><li>• If the problem persists, please contact our customer service department toll-free at (800) 276-6286 or through email at CustomerService@AromaCo.com.</li></ul>



# WARRANTY

## LIMITED WARRANTY

Aroma Housewares Company warrants its products against defects in material and workmanship for five years from provable date of purchase in the United States.

Within this warranty period, Aroma Housewares Company will repair or replace, at its discretion, defective parts at no charge, provided the product is returned, freight prepaid with proof of purchase and U.S. \$15.00 for shipping and handling charges payable to Aroma Housewares Company.

Before returning an item, please call the toll free number below for a return authorization number. Allow 2-4 weeks for return shipping.

This warranty does not apply if the warranty period expired; the products has been modified by any unauthorized service center or personnel; the defect was subject to abuse, improper use not conforming to product manual instructions, or environment conditions more severe than those specified in the manual and specification, neglect of the owner or improper installation; the defect was subject to Force Majeure such as flood, lightning, earthquake, other natural calamities, war, vandalism, theft, brownouts or sags (damage due to low voltage disturbances).

This warranty gives you specific legal rights, which may vary from state to state, and does not cover areas outside the United States.

AROMA HOUSEWARES COMPANY  
6469 Flanders Drive  
San Diego, California 92121  
1-800-276-6286  
M-F, 8:30 AM - 4:30 PM, Pacific Time  
Website: [www.AromaCo.com](http://www.AromaCo.com)



# WARRANTY

## SERVICE AND SUPPORT

In the event of a warranty claim, or if service is required for this product, please contact Aroma® customer service toll-free at:

1-800-276-6286  
M-F, 8:30AM-4:30PM, Pacific Time

Or we can be reached online at [CustomerService@AromaCo.com](mailto:CustomerService@AromaCo.com).

For your records, we recommend stapling your sales receipt to this page along with a written record of the following:

Date of Purchase: \_\_\_\_\_

Place of Purchase: \_\_\_\_\_



**NOTE**

- Proof of purchase is required for all warranty claims.