

# AROMA®



## QUICK & EASY COOKING GUIDE

.....  
For your 14-rice cup Rice Cooker

# **BON APPETIT**

.....


Thank you for choosing an Aroma rice cooker, and welcome to our growing community of home chefs.

Whether you're a seasoned cook or a beginner in the kitchen, this guide will help you get the most out of your rice cooker.

Don't forget – there's even more to discover on social media. Follow us @aromahousewares for more recipe ideas, cooking tips, and inspiration!

***Let's get started!***

## **CONTACT INFO**



@AromaHousewares  
[www.AromaCo.com](http://www.AromaCo.com)

### **Contact Us**

We're here to help! Get in touch with our customer care team for product recommendations, replacement parts, and answers to all your questions.

**Email** [Customerservice@aromaco.com](mailto:Customerservice@aromaco.com)

**Call** 1-800-276-6286 (toll-free)

**Hours** Mon-Fri, 8:00am-4:30pm PST

# TABLE OF CONTENTS

.....


<b>How to Cook White Rice</b>	4	<i>Creamy Cheesecake</i>	22
<i>White Rice Chart</i>	5	<i>Teriyaki Shrimp &amp; Rice</i>	23
<b>How to Cook</b>		<i>One-Pot Spanish Quinoa</i>	24
<i>Brown Rice</i>	6	<i>BBQ Meatballs</i>	25
<i>Quinoa</i>	7	<i>Goulash</i>	26
<i>Oatmeal</i>	8	<i>Chocolate Pumpkin Cake</i>	27
<b>How to Cook Soup</b>	9	<i>Sausage &amp; Egg Casserole</i>	28
<b>Recipe</b>	10	<i>Sausage &amp; Lentil Stew</i>	29
<i>Apple Cinnamon Oatmeal</i>	11	<i>Navy Bean Soup</i>	30
<i>Creamy Corn Egg Drop Soup</i>	12		
<i>One-Pot Tomato Rice</i>	13		
<i>Chicken Noodle Soup</i>	14		
<i>Beef Chili</i>	15		
<i>Cilantro Lime Rice</i>	16		
<i>Macaroni &amp; Cheese</i>	17		
<i>One-Pot Pasta</i>	18		
<i>Frottata</i>	19		
<i>California-Style Egg Muffins</i>	20		
<i>Curry Couscous</i>	21		

# HOW TO COOK WHITE RICE


---

1. Measure rice using the provided rice measuring cup. Over fill the cup slightly, then level it off at the brim of the cup for an accurate measurement.
2. Rinse measured rice in a bowl of water before adding to the inner pot. Rinse rice for 10 seconds and drain the water. Repeat this process at least 2 times, or until the water runs clear.
3. Add rinsed rice to the inner pot, filling up to the line that matches the number of cups of rice.
4. Place the pot into the rice cooker and put the lid on top.
5. Plug the power cord into a nearby 120-volt AC wall outlet.
6. Press the **COOK** switch down to turn on the indicator light and start cooking.
7. The **COOK** switch will automatically flip up to the **WARM** mode when white rice is ready.
8. Stir and fluff with the spatula before serving.
9. Unplug the power cord to turn off the rice cooker before cleaning.


## Tips



- Fill to the top of your rice measuring cup




- Rinse and drain rice to remove starch



- Look for water lines inside the pot

## Note

- **Always use the included rice measuring cup (Rice Cup) for above table**  
1 Rice Measuring Cup =  $\frac{3}{4}$  U.S. Cup (180ml)




# WHITE RICE CHART

WHITE RICE uncooked	WATERLINE inside the Pot	COOK TIME on average	YIELDS cooked rice
2 Rice Cup	Line 2 (≈ 450 ml)	15-20 Min.	4 Rice Cups
3 Rice Cup	Line 3 (≈ 675 ml)	19-24 Min.	6 Rice Cups
4 Rice Cup	Line 4 (≈ 900 ml)	23-28 Min.	8 Rice Cups
5 Rice Cup	Line 5 (≈ 1080 ml)	28-33 Min.	10 Rice Cups
6 Rice Cup	Line 6 (≈ 1260 ml)	32-37 Min.	12 Rice Cups
7 Rice Cup	Line 7 (≈ 1440 ml)	36-41 Min.	14 Rice Cups

## Note

- Not all rice types or brands are the same, so results and timings may vary.
- Do not leave food in the cooker on **WARM** mode for more than 12 hours.
- Before cooking, we recommend rinsing rice in a pot or bowl, not a strainer.
- To add more flavor to rice, try substituting a favorite meat or vegetable broth or stock. The ratio of broth/ stock to rice will be the same as water to rice.
- Before placing the inner pot into the cooker, check that the inner pot is dry and free of debris. Adding the inner pot when wet may damage the cooker.
- After cooking, the inner pot will be very hot. Be sure to use heat-resistant gloves or protective oven mitts to remove the inner pot from the cooker.
- **Always use the included rice measuring cup (Rice Cup) for above table**  
1 Rice Measuring Cup =  $\frac{3}{4}$  U.S. Cup (180ml)




# HOW TO COOK BROWN RICE

1. Use the provided measuring cup to pour rice into the inner pot.
2. Rinse rice in the pot for 10 seconds and drain the water. Repeat at least 3 times, or until the water runs clear.
3. Add water to the pot, filling up to the line that matches the number of cups of rice.
4. Place the pot into the rice cooker and put the lid on top.
5. Plug the power cord into a nearby 120-volt AC wall outlet.
6. Press the **COOK** switch down to turn on the indicator light and start cooking.
7. The **COOK** switch will automatically flip up to the **WARM** mode when your rice is ready.
8. Stir and fluff with the spatula before serving.
9. Unplug the power cord to turn off the rice cooker before cleaning.

WHITE RICE uncooked	WATERLINE inside the Pot	COOK TIME on average	YIELDS cooked rice
2 Rice Cup	Line 2 (≈ 450 ml)	21-26 Min.	4 Rice Cups
3 Rice Cup	Line 3 (≈ 675 ml)	32-37 Min.	6 Rice Cups
4 Rice Cup	Line 4 (≈ 900 ml)	42-47 Min.	8 Rice Cups
5 Rice Cup	Line 5 (≈ 1080 ml)	53-58 Min.	10 Rice Cups

## Note

- Always use the included rice measuring cup (Rice Cup) for above table  
1 Rice Measuring Cup =  $\frac{3}{4}$  U.S. Cup (180ml)



# HOW TO COOK

## Quinoa


.....

1. Use the provided measuring cup to pour rice into the inner pot.
2. Rinse rice in the pot for 10 seconds and drain the water. Repeat at least 3 times, or until the water runs clear.
3. Add water to the pot, filling up to the line that matches the number of cups of rice.
4. Place the pot into the rice cooker and put the lid on top.
5. Plug the power cord into a nearby 120-volt AC wall outlet.
6. Press the cooking switch down to turn on the indicator light and start cooking.
7. The **COOK** switch will automatically flip up to the **WARM** mode when your rice is ready.
8. Stir and fluff with the spatula before serving.
9. Unplug the power cord to turn off the rice cooker before cleaning.

QUINOA uncooked	WATER or broth	YIELDS cooked	Max grain uncooked
1 Rice Cup	1½ Rice Cups (≈ 270 ml)	2½ Rice Cups	4 Rice Cups

### Note

- Always use the included rice measuring cup (Rice Cup) for above table  
1 Rice Measuring Cup = ¾ U.S. Cup (180ml)



# HOW TO COOK OATMEAL


1. Use the provided measuring cup to pour oatmeal into the inner pot.
2. Add water to the pot, according to the chart below.
3. Place the pot into the rice cooker, stir, and **leave the top open without a lid**.
4. Plug the power cord into a nearby 120-volt AC wall outlet.
5. Press the **COOK** switch down to turn on the indicator light and start cooking.
6. The **COOK** switch will automatically flip up to the **WARM** mode when your oatmeal is ready.
7. Stir and fluff with the spatula before serving.
8. Unplug the power cord to turn off the rice cooker before cleaning.

ROLLED OATS uncooked	WATER or broth	YIELDS cooked	Max grain uncooked
1 Rice Cup	2 Rice Cups (≈ 360 ml)	2 Rice Cups	3 Rice Cups

STEEL-CUT OATS uncooked	WATER or broth	YIELDS cooked	Max grain uncooked
1 Rice Cup	3 Rice Cups (≈ 540 ml)	2 Rice Cups	2½ Rice Cups

## Note

- **Always use the included rice measuring cup (Rice Cup) for above table**  
1 Rice Measuring Cup = ¾ U.S. Cup (180ml)





# HOW TO COOK SOUP

.....

1. Add ingredients to the inner pot, up to the maximum water line (3).
2. Carefully place the pot inside the rice cooker. To prevent boiling over, leave the top open without a lid.
3. Plug the power cord into a nearby 120-volt AC wall outlet.
4. Press the cooking switch down to turn on the indicator light and start heating.
5. Stir occasionally with a long-handled wooden spoon or heat-safe utensil.
6. When your soup is ready to serve, press the **COOK** switch up for the **WARM** mode.
7. Unplug the power cord to turn off the rice cooker before cleaning.

## Note

- Avoid cooking for more than 60 minutes, in order to protect your appliance's heating element and avoid overcooking.
- Do not use the provided serving spatula to stir hot soup, chili, or stew. It is not intended to be used in contact with high temperatures. Use a long-handled wooden or heat-safe spoon to stir food while sautéing.



# RECIPE



Make healthy, delicious dishes with ease.  
We're here to help.



# Apple Cinnamon Oatmeal

---

## SERVES 4-6.

4 cup	Apple juice
2 cup	Water
2 cup	Steel-cut oats
2 cup	Dried mixed fruit
2 tbsp	Brown sugar
2 tbsp	Butter
1 tsp	Cinnamon
1 dash	Nutmeg
½ tsp	Salt
2 tbsp	Lemon juice

- Add all ingredients to the pot and mix well.
- Place the inner pot in the rice cooker (without a lid) and press the **COOK** switch down.
- After 10 minutes, carefully stir with a long-handled wooden spoon, avoiding hot steam.
- Continue cooking until the rice cooker automatically switches to **WARM**.
- Wait 10 minutes, then stir and serve with a sprinkle of sugar on top, if desired.



# Creamy Corn Egg Drop Soup

.....

## SERVES 5.

1½ can	Sweet creamed corn
3 cup	Chicken stock
3	Egg
3	Green onion, chopped
3 slice	Thick-cut ham

- Pour chicken stock, green onion whites, and corn into the inner pot.
- Place the inner pot in the rice cooker (without a lid) and press the **COOK** switch down.
- Crack eggs into a small bowl and beat with a whisk.
- After 15 minutes, add eggs to the soup while constantly stirring.
- Serve in bowls with sliced ham on the side.



# One-Pot Tomato Rice

.....

## SERVES 4.

4 cup	Rice
1 cup	Sausage, diced
1 cup	Corn
1 cup	Onion, diced
1 cup	Mushroom, diced
1 cup	Carrot, diced
1 cup	Pea
1 large	Tomato
4 cup	Water

- Pour all ingredients into the rice cooker (except the tomato) and stir.
- Using a knife, cut an 'X' across the bottom of the tomato and add it to the top of the pot.
- Place the inner pot in the rice cooker, close the lid, and press the **COOK** switch down.
- Immediately after the rice cooker switches to **WARM** mode, stir and serve.



# Chicken Noodle Soup

.....

## SERVES 4.

1 tbsp	Olive oil
1 cup	Onion, diced
1 cup	Carrot, sliced
4 tsp	Garlic, minced
2	Chicken breast, cubed
6 cup	Chicken stock
1 cup	Rotini pasta
To taste	Salt and pepper

- Add olive oil, onion, carrot, garlic to inner pot.
- Press the **COOK** switch down, sauté for 5 minutes.
- Add the pasta, chicken, chicken broth, stir to combine. Do not place the glass lid on top.
- Cook for approximately 15 minutes. Season with salt and pepper and push the cook switch up to switch the cooker to **WARM** mode. Serve hot.



# Beef Chili

.....

## SERVES 4.

2 lb	Ground beef	2 cup	Beef broth
2 tbsp	Olive oil	To taste	Salt and pepper
2 cup	Black bean		
2 cup	Kidney bean		
4 tbsp	Chili powder		
4 tbsp	Tomato paste		
2 cup	Diced tomato		
½ cup	Chili seasoning		

- Add olive oil, ground beef to inner pot.
- Press the **COOK** switch down, sauté for 10 minutes.
- Add all remind ingredients to inner pot and stir. Do not place the glass lid on top.
- Cook until the cycle done and cook switch to **WARM** mode. Serve hot.



# Cilantro Lime Rice

---

## SERVES 4.

2 tsp	Olive oil
1 cup	Onion, chopped
2 tbsp	Garlic, minced
2 cup	Long grain rice
3 cup	Water
4 tbsp	Fresh squeezed lime juice
½ cup	Cilantro, chopped
To taste	Salt

- Add olive oil, and onion to the inner pot.
- Press the **COOK** switch down, sauté for 5 minutes.
- Add garlic, rice, water, and salt to the inner pot and stir to combine.
- Place the glass lid on top and cook until the cycle is done and cook switch to **WARM** mode. Fluff rice and serve hot.





# Macaroni & Cheese

.....

## SERVES 4.

4 cup	Macaroni pasta
3 cup	Chicken stock
1 tsp	Salt
1 cup	Milk
2 cup	Cheddar cheese, shredded
2 tbsp	Butter
1 cup	Skim mozzarella cheese
To taste	Salt and pepper

- Add the pasta, chicken stock, milk, and salt to the inner pot and place the glass lid on top.
- Press the **COOK** switch down and cook until all liquid is absorbed.
- Carefully remove the lid and add the cheese, and butter, and stir well.
- Cook until the cycle is done and cook switch to **WARM** mode, and serve.



# One-Pot Pasta

.....

## SERVES 4.

4 cup	Pasta (elbow macaroni, bow tie or corkscrew pasta)
4 cup	Water or chicken broth
2 cup	Pasta sauce of your choice
2 cup	Shredded cheese of your choice
2 tsp	Olive oil
--	Basil leaves, for garnish

- Combine all ingredients except the cheese in the inner pot.
- Place the lid on top and press the **COOK** switch down to begin heating.
- Carefully open the lid to stir occasionally with a long-handled heat-safe spoon.
- When the cooker automatically switches to **WARM**, open the lid and stir in the cheese. Allow the cheese to melt by replacing the lid and cooking for an additional 5 minutes. Serve with more cheese and basil leaves if desired.



# Frittata

.....

## SERVES 4.

8	Egg
4 slice	Deli meat of your choice, chopped
4	Small tomato, chopped
2 cup	Spinach
2 cup	Cheese, shredded
1 pinch	Salt and pepper

- Combine all ingredients in the inner pot and mix well.
- Place the lid on top and press the **COOK** switch down to begin heating.
- When the cooker automatically switches to **WARM**, allow the frittata to rest for an additional 5 minutes or until the eggs are fully set then serve.



# California-Style Egg Muffins

.....

## SERVES 4.

4 tbsp	Butter
4	Whole wheat english muffin, halved
4 slice	Canadian bacon
4	Egg
--	Avocado slices, for garnish

- Press the **COOK** switch down to begin preheating the inner pot. Add the butter and allow it to fully melt.
- Cut a quarter-sized hole in the middle of the Canadian bacon and English muffin.
- Once the butter has melted, first place the English muffin into the inner pot then top with the Canadian bacon slice. Crack the egg into the quarter-sized hole.
- Place the lid on top and allow the cooker to heat until it automatically switches to **WARM**. If additional cooking is needed, let the sandwich sit in the inner pot on Warm for 5 minutes or until fully cooked.
- Slide onto a plate and top with avocado slices, salt, pepper and paprika if desired.



# Curry Couscous

---

## SERVES 4.

2 tsp	Olive oil
1 cup	Onion, chopped
1 cup	Red bell pepper, diced
8	Garlic cloves, minced
2 cup	Couscous
4 cup	Chicken broth
1 tsp	Curry powder
1 tsp	Cumin

- Press the **COOK** switch down to begin preheating the inner pot. Add oil and allow it to heat for 3 minutes.
- Add in garlic, red pepper and onions and cook for 5 minutes or until the onions are translucent.
- Stir in the cumin, chicken broth, curry powder and couscous.
- Place the lid on top and allow the couscous to cook until the cooker automatically switches to **WARM** then serve.



# Creamy Cheesecake

.....

## SERVES 4.

32 oz.	Cream cheese, softened
4 cup	Sugar
4	Egg
2 tsp	Vanilla extract
--	Cooking spray

- Beat the cream cheese, sugar, egg and vanilla with a mixer until the consistency is smooth.
- Lightly coat the inner pot with cooking spray then pour the cheesecake mixture in.
- Place the lid on top and press the **COOK** switch down to begin heating.
- When the cooker automatically switches to **WARM**, allow the cheesecake to rest for an additional 30 minutes.
- Refrigerate for 2-3 hours then serve cold with mixed berries and whipped cream if desired.



# Teriyaki Shrimp & Rice

.....

## SERVES 4-6.

20	Raw medium shrimp
1 cup	Sweet onion, chopped
1 cup	Frozen peas
2 cup	Jasmine rice
4	Garlic clove, minced
2 tsp	Fresh ginger, grated
3 cup	Water
1 cup	Soy sauce
4 tbsp	Brown sugar

- Add the onion, peas, rice, garlic, ginger and water to the inner pot and mix thoroughly.
- Once all ingredients have been combined, place the shrimp on top.
- Place the lid on and press the **COOK** switch down to begin heating.
- After the cooker automatically switches to **WARM**, stir in the soy sauce and brown sugar then serve.



# One-Pot Spanish Quinoa

## SERVES 4.

4	Italian sausage link, sliced	1 pinch	Cumin powder
1 tbsp	Olive oil	1 pinch	Salt and pepper
4	Garlic clove, minced	2	Avocado, diced
2 cup	Quinoa	1 tbsp	Lemon juice
3 cup	Chicken broth	--	Cilantro, for garnish
1 cup	Corn kernels		
1 cup	Tomato, diced		
2 tsp	Chili powder		

- Add the sausage, olive oil, garlic, quinoa, chicken broth, corn, diced tomatoes, chili powder, cumin, salt and pepper to the inner pot and mix thoroughly.
- Place the lid on top and press the **COOK** switch down to begin heating.
- When the cooker automatically switches to **WARM**, fluff the quinoa slightly then serve with lemon juice, avocado, and cilantro.





# BBQ Meatballs

.....

## SERVES 4-6.

2 tsp	Olive oil
24 oz	Frozen meatballs
1 cup	Yellow onion, chopped
2 cup	BBQ sauce
8 cup	Cabbage, shredded
1 cup	Cheddar cheese, shredded

- Add the olive oil, meatballs, onion, and BBQ sauce to the inner pot and mix thoroughly.
- Place the lid on top and press the **COOK** switch down to begin heating.
- Allow the meatballs to cook for 10 minutes then using caution, remove the lid and mix in the shredded cabbage.
- After the cooker automatically switches to **WARM**, stir in the cheddar cheese and cook for an additional 2 minutes or until all the cheese has melted then serve.



# Goulash

.....

## SERVES 4-6.

1 tsp	Olive oil	4 cup	Elbow macaroni
1 cup	Yellow onion, chopped	1 cup	Water
4	Garlic clove, minced	To taste	Salt
2 cup	Bell pepper, chopped		
1 lb.	Ground beef		
2 cup	Tomato, diced		
½ cup	Tomato paste		
4 tsp	Italian seasoning		

- Add all ingredients to the inner pot and mix thoroughly.
- Place the lid on top and press the **COOK** switch down to begin heating.
- After the cooker automatically switches to **WARM**, add salt to taste then serve.



# Chocolate Pumpkin Cake

.....

## SERVES 8.

2 cup	Pancake mix
2 cup	Water
1 cup	Pumpkin puree
1 cup	Chocolate chips
--	Cooking spray

- In a large bowl, whisk together the pancake batter and water. Once incorporated, stir in the pumpkin purée and chocolate chips.
- Lightly coat the inner pot with cooking spray then pour the batter in.
- Place the lid on top and press the **COOK** switch down to begin heating.
- Allow the cake to cook for about 20 minutes or until you can insert a toothpick into the middle and remove it with no batter sticking to it.
- Serve **WARM** with a drizzling of melted chocolate, powdered sugar, maple syrup, berries, or whipped cream.



# Sausage & Egg Casserole

---

## SERVES 4.

1 lb	Ground pork sausage
8	Large egg
2 cup	Milk
1 tsp	Salt
1 tsp	Ground mustard
4 slice	White bread, cubed
1 cup	Cheddar cheese, shredded

- In a large bowl, beat the eggs then mix in the milk, salt and mustard.
- Once combined, stir in the bread cubes, cheese and ground sausage.
- Pour the egg mixture into the inner pot.
- Place the lid on top and press the **COOK** switch down to begin heating.
- After the cooker automatically switches to **WARM**, allow the casserole to rest for an additional 25 minutes or until the eggs have set then serve.



# Sausage & Lentil Stew

.....

## SERVES 4.

4	Italian sausage link, sliced	1 tsp	Cayenne
1 cup	Yellow onion, chopped	1 tsp	Smoked paprika
1 cup	Zucchini	1 tsp	Ground cumin
4 cup	Carrot, cubed	1 tsp	Dried oregano
4	Celery stalk, sliced	8 oz	Frozen spinach
4	Garlic clove, minced		
2 cup	Lentil		
8 cup	Chicken broth		

- Add the sausage and vegetables to the inner pot and mix thoroughly.
- Press the **COOK** switch down to begin heating.
- Sauté the sausage and vegetables until the sausage is no longer pink.
- Add the lentils, cayenne, cumin, smoked paprika, oregano, and chicken broth then place the lid on top.
- After the cooker automatically switches to **WARM**, stir in the frozen spinach then press the cook switch down once more.
- Allow the stew to cook until the cooker automatically switches to Warm again, then serve.



# Navy Bean Soup

.....

## SERVES 4-6.

4	Italian sausage link, cubed	1 tsp	Dried thyme
1 cup	Yellow onion, chopped	½ tsp	Dried rosemary
8	Garlic cloves, minced	12 cup	Water
4 cup	Fresh baby spinach	To taste	Salt
4 cup	Carrot, cubed		
4	Celery stalk, sliced		
2 cup	Dry navy beans		
3	Bay leaf		

- Soak the navy beans in water overnight in the refrigerator.
- Add the sausage, onion, garlic, spinach, carrots and celery to the inner pot and mix thoroughly.
- Press the **COOK** switch down to begin heating.
- Sauté the sausage and vegetables until the sausage is no longer pink.
- Add the soaked navy beans, bay leaf, thyme, rosemary, and water then place the lid on top.
- After the cooker automatically switches to Warm, press the cook switch down once more.
- Allow the soup to cook until the cooker automatically switches to **WARM** again, then add salt to taste and serve.

# JOIN THE COMMUNITY

---

## #CookwithAroma

We can't wait to see what you cook up! Join our growing community of home chefs on social media and discover hundreds of healthy new recipes.

**Share your creations on social media and let's savor the joy of cooking together, creating a vibrant tapestry of tastes.**



@AromaHousewares  
[www.AromaCo.com](http://www.AromaCo.com)