



Congelador Para Helado  
de 4-Cuartsos

Manual de instrucciones

# AROMA®

## 4-Quart Ice Cream Maker

Instruction Manual



# AROMA®

Congratulations on your purchase of the **AROMA**® Old-Fashioned Ice Cream Maker! This convenient, easy-to-use appliance makes all of your favorite frozen treats, just the way you like them. Enjoy ice cream, frozen yogurt, sorbet and gelato custom-made to your taste!

The origin of ice cream dates back into ancient history, but the very first traditional hand-cranked ice cream churner was developed in America in the nineteenth century. With the addition of milk and the development of modern refrigeration, ice cream became the widespread sensation that it is today with thousands of varieties available to people everywhere in the world.

With the Aroma® Old-Fashioned Ice Cream maker, celebrating the great American tradition of ice cream is quick, easy and delicious. For the kids, whipping up chocolate, vanilla or strawberry recipes is a snap, with variations made easy—crumble up your favorite candy, cookie or topping and stir it in for a whole new flavor! The motorized crank does the work for you at the touch of a button, or you can take turns with the hand-crank for some good old-fashioned fun.

Use the recipes included in this manual to make timeless family recipes, or experiment to create your own unique flavors. For healthier options, try low-fat, sugar-free or non-dairy ice cream varieties.

Whatever your preference, the Aroma® Old-Fashioned Ice Cream Maker is a fun, fast and easy way to enjoy the timeless tradition of fresh, homemade ice cream.

For recipe suggestions or more kitchen solution ideas, please visit us online at [www.AromaCo.com](http://www.AromaCo.com).

Please read all instructions before first use

**Published By:**

Aroma Housewares Co.  
6469 Flanders Drive  
San Diego, CA 92121  
U.S.A.  
1-800-276-6286  
[www.aromaco.com](http://www.aromaco.com)

© 2008 Aroma Housewares Company All rights reserved.

© 2008 Aroma Housewares Company. Todos los derechos reservados.

Aroma Housewares (6469 Flanders Drive, San Diego, CA 92121, U.S.A.) 1-800-276-6286 www.aromaco.com

Publicada Por:

Para consejos sobre recetas o ideas para nuevos aparatos para su hogar, por favor visitenos en linea a [www.AromaGlo.com](http://www.AromaGlo.com).

Quadrúnguila que sea su preferencia, la maguncia para hacer heridas a la antigua de Aroma® es una forma divergida, rápida y fácil de disfrutar la tradición eterna del

Últimamente las recetas medicinales en este marco, preparar recetas familiares tradicionales o experimentante con la creación de sus propios sabores únicos. Para variaciones más saludables, también hay opciones bajas en calorías, sin azúcar y

Con la madera para hacer helados a la antigua de Aroma®, celebra la gran tradición estadounidense del helado resulta rápido, fácil y delicioso. ¡Para los niños, preparar recetas de chocolate, vainilla o fresa es rápido, con variaciones totalmente nuevas! La manivela motorizada hace todo el trabajo por usted con el toque de un botón, o se puede turnar con la manivela para divertirse a la antigua.

El origen del hébreo data de las épocas antigüas, aunque la primera manifestación tradicional hecha a mano para preparar hébreo se desarrolló en los Estados Unidos en el siglo XIX. Con la adición de leche y el desarrrollo de la refinería moderna, el hébreo se ha convertido en la sensación generalizada del presente, con miles de variedades disponibles para la gente en todo el mundo.

**AROMA**. Esté apurado conviniénte y fácil de usar hace todos sus postres congelados favoritos justo como a usted le agrada. ¡Disfrute de helados, yogurts congelados y niñeras hechos a la medida de su gusto!

# GUARDE ESTAS INSTRUCCIONES

1. Por favor lea todas las instrucciones.
  2. No toque las superficies calientes. Utilice los mangos y las perillas.
  3. Para protegerse y evitar un choque eléctrico, asegúrese que no queden cerca de niños. Este aparato no está hecho para ser usado por niños.
  4. Es necesario ejercer una estrecha vigilancia cuando se use el aparato motor eléctrico.
  5. Descubra el aparato de la toma eléctrica cuando no se esté en uso, antes de limpiarlo y antes de ponerle o quitarle partes.
  6. Evite el contacto con las partes que estén en movimiento. Mantenga los dedos, el cablelo, la ropa, así como espatulas y otros utensilios alejados de la máquina.
  7. No ponga a funcionar este aparato si el cordón eléctrico o la clavija de durante el funcionamiento del aparato.
  8. El uso de accesorios eléctricos no recomendados por el fabricante del aparato pueden provocar incendios, electrocusiones, o lesiones personales.
  9. No se use en exteriores.
  10. No deseje que el cordón caulegue del borde de la mesa ni del mostrador, ni que toque superficies calientes.
  11. No utilice el aparato para otro uso que no sea el indicado.
  12. No coloque el aparato sobre o cerca de un quemador de gas o eléctrico ni dentro de un horno caliente.
  13. Para desconectar el aparato, presione el interruptor a la posición de apaga do, "OFF". Y luego saque la clavija del enchufe de la pared.
  14. Nunca ponga a funcionar la máquina de hacer helado, estando en seco su recipiente interior. Siempre que esté conectada tenga mezcla de helado dentro del recipiente.
  15. No ponga caliente ni otros líquidos calientes dentro del aparato.
- Siempre enfríe la mezcla antes de batir.

## IMPORTANT SAFEGUARDS

*Basic safety precautions should always be followed when using electrical appliances, including the following:*

1. Important: Read all instructions carefully before first use.
2. Do not touch hot surfaces. Use handles or knobs.
3. To protect against electrical shock, do not immerse cords, plugs or the electric motor in water or other liquids.
4. Close supervision is necessary when any appliance is used by or near children.
5. Unplug from outlet when not in use, before cleaning, and before putting on or taking off parts.
6. Avoid contact with moving parts. Keep fingers, hair, clothing and utensils away during operation.
7. Do not operate any appliance with a damaged cord or plug, after the appliance malfunctions or has been damaged in any manner. Return appliance to the nearest authorized service facility for examination, repair or adjustment.
8. The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
9. Do not use outdoors.
10. Do not let cord hang over edge of table or counter, or touch hot surfaces.
11. Do not use the appliance for other than its intended use.
12. Do not place this appliance on or near a hot gas or electric burner, or in a heated oven.
13. To disconnect power, press switch to "OFF" position and then remove plug from wall outlet.
14. Never operate ice cream maker dry. Always have ice cream mixture in the container while plugged in.
15. Do not use hot oil or liquids in ice cream maker. (Always chill mixtures before churning.)

## SAVE THESE INSTRUCTIONS

## SHORT CORD INSTRUCTIONS

1. A short power-supply cord is provided to reduce the risks resulting from becoming entangled in or tripping over a longer cord.
2. Longer extension cords are available and may be used if care is exercised in their use.
3. If a longer extension cord is used:
  - a. The marked electrical rating of the extension cord should be at least as great as the electrical rating of the appliance.
  - b. The longer cord should be arranged so that it will not drape over the counter top or tabletop where it can be pulled by children or tripped over unintentionally.



## POLARIZED PLUG

This appliance has a polarized plug (one blade is wider than the other); follow the instructions below:

To reduce the risk of electric shock, this plug is intended to fit into a polarized outlet only one way. If the plug does not fit fully into the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not attempt to modify the plug in any way.

**THIS APPLIANCE IS FOR HOUSEHOLD USE ONLY.**

## ESTE APARATO ES PARA USO DOMESTICO.

Para reducir el riesgo de descarga eléctrica, este artefacto electrodoméstico tiene un enchufe polarizado (una clavija es más ancha que la otra). Como una característica de seguridad eléctrica, este artefacto electrodoméstico polarizado sólo se adapta de una manera. Si no entra totalmente en el tomacorriente, de vuelta el enchufe. Si tam poco entra, comuníquese con un electricista competente. No intente de modificar el enchufe, es muy peligroso.

Si este aparato tiene un enchufe polarizado:





## ENCHUFE POLARIZADO



1. Se proporcione un cordón eléctrico corto para reducir los riesgos de que alguien se tropiece o entre en un cordón más largo.
  2. Se puede usar un cordón de extensión con cuidado. Si se usa un extensión sea por lo menos igual o mayor que la corriente eléctrica nominal del aparato.
  3. Cordon de extensión:
- a. Asegúrese de que la capacidad eléctrica nominal del cordón de extensión sea por lo menos igual o mayor que la corriente eléctrica nominal del aparato.
  - b. Asegúrese de que el cordón de extensión no caiga del mostrador o mesa donde pudiera ser tirado por un niño o donde alguien se pudiera tropezar.

## INSTRUCCIONES DE CABLE CORTO

## PARTS IDENTIFICATION



# USING YOUR ICE CREAM MAKER

## Before First Use:

1. Read all instructions and important safeguards.
  2. Remove all packaging materials and make sure items have been received in good condition.
  3. Tear up all plastic bags, as they can pose a risk to children.
  4. Wash the lid, freezer canister and all accessories in warm, soapy water.
  5. Rinse and dry all parts thoroughly.
  6. Wipe electric motor with a damp cloth.
  7. Pour water (about 2/3 full) into the wooden bucket and leave in the sink or water-safe area for one and a half hours. This will give the wood a chance to expand so that the salt/ice mixture will not leak out during the freezing process.
- Do not use abrasive cleaners or scouring pads.
  - Do not immerse the base, cord or plug in water at any time.

## To Make Ice Cream:

### SEE STEP 7 IN “BEFORE FIRST USE” SECTION BEFORE BEGINNING

1. Select your favorite recipe (see “*Recipes*” beginning on **page 10** for some classic ice cream recipes); prepare ingredients per recipe instructions. Chill the mixture in the refrigerator until cold. Chill the ice cream canister in the freezer (towards the back) for at least one hour (overnight is recommended).
2. Pour chilled ice cream mixture into chilled ice cream canister (fill no more than 2/3 full as mixture will expand during freezing process).
3. Insert the dasher and make sure the bottom of dasher is fixed in the center of the bottom of the canister. (Figure 1)
4. Place the lid on the canister. (Figure 2)




Figure 1






Figure 2

4



1. Seleccione el número 6 de “Antes de usarla por primera vez” antes de empezar.
2. Agregue la mezcla fría del helado dentro del bote frío para el helado (solo haga lo que sea necesario). Enfrié la mezcla en el refrigerador hasta que esté completamente fría. Enfrié el bote para el helado en el congelador las instrucciones de la receta. Una vez que el refrigerador ha alcanzado su capacidad, ya que la mezcla se expandirá durante el proceso de congelamiento.
3. Inserte la agitadora y asegúrese que su parte inferior quede fija en el centro de la base del helado.
4. Coloque la tapadera sobre el bote. (Dibujo 2)

- Nunca sumerja en agua ni en otro líquido, la base ni el cordón eléctrico.
- No utilice limpiadores abrasivos ni fibras para lavar.

### Para hacer helado:

1. Antes de usar el congelador para helado de garrafa por primera vez:
  1. Lea todas las instrucciones y las medidas de seguridad importantes.
  2. Retire todos los materiales de empaque y asegúrese de que los artículos se reciban en buenas condiciones.
  3. Rompa todas las bolsas de plástico, ya que pueden representar un riesgo para los niños.
  4. Lave en agua tibia con jabón la cubierta, la garrafa del congelador y todos los accesorios.
2. Antes de usar el congelador para helado de garrafa por primera vez:
  1. Lea todas las instrucciones y las medidas de seguridad importantes.
  2. Retire todos los materiales de empaque y asegúrese de que los artículos se reciban en buenas condiciones.
  3. Rompa todas las bolsas de plástico, ya que pueden representar un riesgo para los niños.
  4. Lave en agua tibia con jabón la cubierta, la garrafa del congelador y todos los accesorios.
3. Antes de usar el congelador para helado de garrafa por primera vez:
  1. Lea todas las instrucciones y las medidas de seguridad importantes.
  2. Retire todos los materiales de empaque y asegúrese de que los artículos se reciban en buenas condiciones.
  3. Rompa todas las bolsas de plástico, ya que pueden representar un riesgo para los niños.
  4. Lave en agua tibia con jabón la cubierta, la garrafa del congelador y todos los accesorios.
4. Antes de usar el congelador para helado de garrafa por primera vez:
  1. Lea todas las instrucciones y las medidas de seguridad importantes.
  2. Retire todos los materiales de empaque y asegúrese de que los artículos se reciban en buenas condiciones.
  3. Rompa todas las bolsas de plástico, ya que pueden representar un riesgo para los niños.
  4. Lave en agua tibia con jabón la cubierta, la garrafa del congelador y todos los accesorios.

### COMO USAR EL APARATO



# USING YOUR ICE CREAM MAKER

## To Make Ice Cream:

14. Unplug and remove motor or hand crank once ice cream has churned for about 40 minutes, or once the motor has stopped (if the motor has stopped prematurely, turn it off, break up any ice blockages with the plastic stirrer and start again).
  15. With one hand on the canister lid to hold it in place (canister will have a tendency to float up in the ice water mixture), remove the motor or hand crank. Carefully lift the mixing canister from the wooden bucket.
  16. Clear the ice and salt away from the top of the ice cream canister. Wipe carefully to remove the salt and water before removing the cover.
  17. Take the dasher out and scrape off excess ice cream with a spatula.
  18. Transfer to a freezable container and freeze, or serve straight from the canister.

## Helpful Hints

- For each batch of ice cream, expect to use 7-14 lbs. of ice. (1-2 medium size bags)
  - Many ice cream recipes call for raw eggs. To eliminate salmonella from your egg mixture, heat it to a temperature of 160°F, but do not boil it. This will make the ice cream safe to eat. You may also use pasteurized eggs in place of raw eggs.
  - Be sure to chill mixture prior to adding to canister.
  - To avoid ice cream seeping out of the canister, do not lay the canister flat when storing in a freezer.
  - For ice cream recipes that require pre-cooking, it is recommended that you make the mixture a day ahead. The mixture will then be able to cool completely and expand. Pre-chilling any ice cream recipe is suggested for achieving the best results.
  - Artificial sweeteners may be substituted for sugar. Use the following proportions for reference:

- 1 packet of sweetener = 2 tsp. sugar
- 6 packets = 1/4 cup
- 8 packets = 1/3 cup
- 12 packets = 1/2 cup

- The churning process should take about 40 minutes.

## COMO USAR EL APPARATO

Para hacer helado


- Para las recetas de helados que requieren algo de coccimiento previo, se recomienda que la mezcla se haga con un día de anticipación. Así se evitará que la mezcla se ponga a helar.
- El proceso de congelamiento se debe durar aproximadamente 40 minutos.
- Se usa aproximadamente 7-14 libras de hielo para cada botella.
- El azúcar se puede sustituir por edulcorantes artificiales. Utilice las siguientes equivalencias como referencia:

  - 1 sobrecito de edulcorante = 1/4 de taza
  - 6 sobrecitos = 1/4 de taza
  - 8 sobrecitos = 1/3 de taza
  - 12 sobrecitos = 1/2 de taza

- Para evitar que el helado se escorra fuera del bote, no lo coloque horizontalmente cuando lo guarde en un congelador.
- No tape el agujero de drenaje a un lado de la cubeta de madera. Esto permitirá que el exceso de agua salada y debiera mantenerse abierta siempre.
- Aségúrese de que haya enfriado la mezcla antes de vaciarla en el bote.
- Muchas recetas requieren huevos crudos. Para eliminar la bacteria salmonela, calientelos hasta una temperatura de 160°F, pero no los ponga a helar. Así se hace seguro comer la mezcla. También se salmoneosis, una enfermedad que se transmite a través de la carne de pescado contaminada.
- Puede usar huevos pasteurizados.

Consejos Utiles

14. Descúnete y retira el motor una vez que el helado se haya batido durante 40 minutos aproximadamente o cuando el motor se detenga (si el motor se detiene prematuramente, apáguelo, rompa cualquier obstrucción de helado que haya con el agitador de plástico e inície de nuevo).
  15. Con una mano sobre la tapadera del bote, retira el motor o la manivela manual de la cubeta de madera. Tenga cuidado - el bote suele volcar en la mezcla de sal, helado, y agua. Retira el bote de la cubeta de madera.
  16. Quite el helado y la sal de la parte superior del bote del helado. Limpie cuidadosamente la agitadora y con una espátula de madera y retira el exceso de helado.
  17. Saque la agitadora y con una espátula de madera y retira el exceso de dosasamente a fin de remover la sal y el agua antes de levantar la cubierta.
  18. Pase el helado a un recipiente para congelar y congélelo o sirvalo directamente del bote (garrafa).



## COMO LIMPIAR EL APARATO

Desconecte siempre la unidad y dese que se enfríe completamente antes de limpiarla.

1. Limpie el motor de accionamiento con una toalla ligeramente húmeda para remover desechos.

2. Limpie perfectamente la cubeta de madera con una esponja con jabón, a fin de quitar los residuos del agua salada. Enjuague y dese que para asegurarse de que la sal no corra las partes metálicas.

3. Lave con agua y jabón y dese que la tapadera hasta que el bote para el helado esté completamente seco.

- No utilice limpiadores abrasivos ni fibras para lavar.
- Este sprayto y los accesorios NO deben lavarse en máquinas lavavajillas.
- No congele el bote (garrafa) cuando este húmedo.

## NOTAS

## HOW TO CLEAN

*Always unplug unit and allow to completely cool before cleaning.*

1. Wipe electric motor with a slightly damp cloth to remove debris.
2. Clean wooden bucket with a soapy sponge thoroughly to remove the saltwater residue. Rinse and dry to ensure the salt does not corrode the metal parts.
3. Wash canister, lid, dasher and stirrer with soapy water and dry thoroughly. Do not replace the lid until the ice cream canister is completely dry.
  - Do not use harsh abrasive cleaners.
  - This appliance and accessories are NOT dishwasher safe.
  - Do not freeze canister when wet.

## NOTES

# TROUBLESHOOTING

<p><b>My ice cream turned out soft or runny.</b></p>	<p>Home-made ice cream traditionally has the consistency of a thick milkshake. If you prefer a firmer consistency, you can:</p> <ul style="list-style-type: none"> <li>• Remove the dasher and place the lid and lid cap on the mixing canister. Place upright in the freezer to harden. Another option is to leave the canister in the wooden bucket, remove dasher, add cap and add more ice to the salt-ice mixture. Cover with a towel and let sit until the ice cream is firm.</li> <li>• For fluffier ice cream, once the electric motor has finished churning, you may remove it and use the hand crank to churn the ice cream to the desired consistency.</li> <li>• The richer the cream you use, the richer the ice cream will be. Heavy whipping cream is suggested for the creamiest, smoothest ice cream. Milk can also be substituted for cream but will alter the texture and taste of the ice cream. You might also consider using a combination of milk and cream for healthier ice cream.</li> <li>• Recipes that call for alcohol may inhibit the freezing process. If you are using an ice cream recipe that calls for alcohol, vanilla or peppermint extract (which contain alcohol), it is best to add it during the last few minutes of the freezing cycle.</li> <li>• Pay close attention to the amount of rock salt used during the making of your ice cream. Using too little salt may inhibit the freezing of your ice cream mixture. Read the instructions in the section titled “<i>To Make Ice Cream</i>” beginning on <b>page 4</b> for more details.</li> </ul>
<p><b>The texture of my ice cream is too hard or grainy.</b></p>	<p>A hard or grainy ice cream texture may be due to one of the following causes:</p> <ul style="list-style-type: none"> <li>• Be sure that once you start churning your ice cream, you <b>DO NOT</b> stop. Stopping for any length of time while churning can cause large ice crystals to form in the mixture, which will give your ice cream a grainy texture.</li> <li>• Pay close attention to the amount of rock salt used during the making of your ice cream. Adding too much salt can cause the mixture to freeze too quickly, which may lead to the formation of ice crystals in your ice cream. Read the instructions in the section titled “<i>To Make Ice Cream</i>” beginning on <b>page 4</b> for more details.</li> </ul>
<p><b>The salt water mixture leaked out of the wooden bucket.</b></p>	<p>Before using the ice cream maker, it is necessary to soak the wooden bucket in water for at least an hour and a half. This allows the wood to expand and prevents leaks. To do so, simply fill up the bucket (about 2/3 full) and let it sit in the sink or other water-safe area for an hour and a half. Pour out the water and the bucket is ready to use!</p>

# TROUBLESHOOTING

<p>• En caso de que la mazulina para hacer helado se pare antes de que el batidoo haya llegado a su término (40 minutos aproximadamente), verifique si no se han atorado los pedazos grandes de helado contra el bote.</p>
<p>• La mazulina para hacer helado se apagará automáticamente mente si los ingredientes dentro del bote están muy espesos para que la placa de la agitadora pueda dar vueltas. La mazulina para hacer helado funcionaría normalmente nuevo una vez que los ingredientes se hayan quedado grandes en la mezcla, como nubes espesos sean retirados del bote.</p>
<p>• Si la receta pide pedazos duros o granules, se o pedazos para chocolate, se pueden atorar contra el bote. Si la receta pide romperlos en pedazos más pequeños para evitar obstrucciones en el bote. También se puede romperlos en pedazos más grandes en la mezcla. Si preferira usénd un helado como mezcla.</p>
<p>• Despues de batido, el helado nuncá será tan dulce como mezcla. Si prefiere agregarlos despues de batir la mezcla.</p>
<p>• Despues de batido, el helado nuncá será tan dulce como mezcla. Si prefiere agregarlos despues de batir la mezcla.</p>
<p>• Despues de batido, el helado nuncá será tan dulce como mezcla. Si prefiere agregarlos despues de batir la mezcla.</p>
<p>• Despues de batido, el helado nuncá será tan dulce como mezcla. Si prefiere agregarlos despues de batir la mezcla.</p>
<p>• Despues de batido, el helado nuncá será tan dulce como mezcla. Si prefiere agregarlos despues de batir la mezcla.</p>

<p><b>The canister or dasher jammed/stopped turning during the churning process.</b></p>	<p>Jamming of the canister or dasher can be due to one of the following causes:</p> <ul style="list-style-type: none"> <li>• Ice may have caused a blockage in the wooden bucket. Turn off the motor and make sure that the ice in the bucket is broken up into small, coarse pieces. The plastic stirrer provided can be used to break up any blockages that may occur.</li> <li>• If the mixture has become too thick, the dasher may become stuck. The mixture in the canister should never become thicker than the consistency of soft-serve ice cream.</li> <li>• If there are hard pieces in the mixture, such as nuts or chocolate chips, they may cause the dasher to become lodged in the canister. It is best to add any such ingredients to your ice cream after the churning process is complete. Another suggestion is to use finely chopped ingredients, such as grated chocolate in place of chocolate chips.</li> <li>• Be sure that once you start churning your ice cream, you <b>DO NOT</b> stop. Stopping can cause the ice cream to harden around the edge of the canister, which will restrict the movement of the dasher and may cause it to become stuck.</li> <li>• If the dasher becomes stuck, check to see if the mixture has frozen around the inside edges of the mixing canister. If it has, use a plastic spoon or spatula to scrape the edges of the canister. The dasher should function normally once the edges have been cleared.</li> </ul>
<p><b>My ice cream mixture tasted fine, but after freezing it my ice cream does not taste the same.</b></p>	<p>Actual ice cream will always taste less sweet than the mixture. You may adjust the amount of sugar in the recipe to suit your taste, keeping in mind that after the freezing process the sweetness of the ice cream will be lessened.</p>
<p><b>My ice cream went bad when I stored it in the freezer.</b></p>	<p>Because home-made ice cream lacks many of the preservatives that come in store-bought ice cream, it does not store as well. Usually home-made ice cream will last about one week when stored in a freezer.</p> <ul style="list-style-type: none"> <li>• To keep ice cream its freshest, place it in an airtight plastic container before storing it in the freezer.</li> </ul>

## Quick & Easy Chocolate Ice Cream

15 Tbsp cocoa  
3 large cans of condensed milk  
6 cups milk

In a large mixing bowl, combine milk and condensed milk. Dissolve the cocoa in a bit of hot water. Once dissolved, stir cocoa into the milk mixture until completely blended. Pour the entire contents of the bowl into the mixing canister and follow directions in the "To Make Ice Cream" section, **pages 4-6**. Do not fill the mixing canister more than 2/3 full, as the mixture will expand during freezing.

## Vanilla Ice Cream

2 cups granulated sugar  
1 1/2 Tbsp cornstarch  
1/4 tsp salt  
1 1/2 Tbsp vanilla  
7 cups milk  
5 eggs, beaten  
2 3/4 cups heavy cream  
1 1/2 cups half and half

Mix the sugar, cornstarch and salt in a large saucepan. Over medium heat, slowly stir in the milk, stirring constantly. Very slowly, add the beaten eggs and continue to stir. Reduce heat to low and cook until mixture thickens slightly. Slowly add vanilla, half and half and heavy cream. Pour into a large glass bowl and refrigerate for 2-4 hours or until mixture has chilled. Remove from refrigerator. Pour mixture into the mixing canister and follow directions in the "To Make Ice Cream" section, **pages 4-6**. Do not fill the mixing canister more than 2/3 full, as the mixture will expand during freezing.

expandiría durante el proceso de congelamiento.  
6. Solo llene el bote hasta 2/3 de su capacidad, ya que la mezcla se instrucciones de la sección "Para Hacer Helado", de las **Páginas 4 a la ador. Vacíe la mezcla en el bote (garrafa) de mezclar y siga las 4 horas o hasta que la mezcla se haya enfriado. Saque la mezcla del refrigerador. Vacíela en un tazón grande de vidrio y refrigerar de 2 a doble crema. Lentamente agregue la vainilla, de mitad crema y mitad leche y la Lentamente agregue la vainilla, de mitad crema y mitad leche y la Reduzca el fuego y cocine hasta que la mezcla espese ligeramente. Muélen taméntate, añada los huevos batidos y continúe revolviendo. Mezcle el azúcar, la maicena y la sal en una cacerola grande. A fuego mediano, agregue lentamente la leche, revolviendo constantemente.**

1 1/2 tazas de mitad crema y mitad leche (half and half)  
2 3/4 tazas de doble crema  
5 huevos batidos  
7 tazas de leche  
1 1/2 cucharaditas de vainilla  
1/4 cucharadas de sal  
1 1/2 cucharaditas de maicena  
2 tazas de azúcar granulada

## Helado de Vainilla

expandiría durante el proceso de congelamiento.  
6. Solo llene el bote hasta 2/3 de su capacidad, ya que la mezcla se instrucciones de la sección "Para Hacer Helado", de las **Páginas 4 a la ador. Vacíe la mezcla en el bote de mezclar y siga las 4 horas o hasta que la mezcla de leche y revuelva hasta que esté completamente mezclada. Vacíe la mezcla de leche y revuelva hasta que esté completamente mezclada. Vacíe la mezcla en un tazón grande de vidrio y refrigerar de 2 a doble crema. Lentamente agregue el cacao a la mezcla de leche y revuelva hasta que esté completamente mezclada. Vacíe la mezcla en el bote de mezclar y siga las 4 horas o hasta que la mezcla se haya enfriado. Saque la mezcla del refrigerador. Vacíela en un tazón grande de vidrio y refrigerar de 2 a doble crema. Lentamente agregue la vainilla, de mitad crema y mitad leche y la**

6 tazas de leche  
3 latas grانdes de leche condensada  
1 5 cucharadas de cacao (en polvo)

## Helado de Chocolate Simple

## RECIPES

### Chocolate Ice Cream

- 2 2/3 cups granulated sugar
- 2 tsp cornstarch
- 1/2 tsp Salt
- 6 cups milk
- 4 eggs, beaten
- 6 squares semi-sweet chocolate, melted
- 1 1/3 cups half and half
- 2 cups whipping cream
- 2 Tbsp vanilla extract

Mix the sugar, cornstarch and salt in a large saucepan. Over medium heat, slowly stir in the milk, stirring constantly until the mixture begins to simmer. Very slowly, add the beaten eggs and continue to stir. Reduce heat to low and cook until mixture thickens slightly. Slowly stir in the melted chocolate and whisk until all chocolate is combined and mixture is smooth. Slowly add vanilla, half and half and heavy cream. Pour into a large glass bowl, cover and refrigerate for 2-4 hours or until mixture has chilled. Pour mixture into the mixing canister and follow directions in the "To Make Ice Cream" section, pages 4-6. Do not fill the mixing canister more than 2/3 full, as the mixture will expand during freezing.

### Coffee Ice Cream

- 4 1/2 cups half and half
- 2 1/4 cups sugar
- 4 1/2 tablespoons instant coffee powder
- 6 cups cream

Combine all ingredients in mixing canister. Stir well until both sugar and instant coffee powder are dissolved. Freeze as instructed. Do not fill the mixing canister more than 2/3 full, as the mixture will expand during freezing.

### Helado de Chocolate

- 2 2/3 tazas de azúcar granulada
- 2 cucharadas de maicena
- 1/2 cucharada de sal
- 6 tazas de leche
- 4 huevos batidos
- 6 cuadros de chocolate semidulce
- 1 1/3 tazas mitad crema y mitad leche (half and half)
- 2 tazas de crema batida

1 cucharada de extracto de vainilla

Mezcle el azúcar, la maicena y la sal en una cacerola grande. A fuego mediano, agregue lentamente la leche, revolviendo constantemente hasta que la mezcla comience a hervir. Muy lentamente, añada los huevos batidos y continúe revolviendo. Reduzca el fuego y cocine la mezcla hasta que espese ligeramente. Reduzca el fuego y agregue poco a poco la vainilla, la 1 2/3 tazas de mitad crema y mitad leche y lentamente la vainilla, la 1 2/3 tazas de mitad crema y mitad leche y la doble crema. Vacíela en un tazón grande de vidrio, tapelo y refrigere de 2 a 4 horas o hasta que la mezcla se haya enfriado.

Vacie la mezcla en el bote (garrafa) de mezclar y siga las instrucciones de la sección "Para Hacer Helado", de las **Páginas 4 a la 6**. Solo llene el bote hasta 2/3 de su capacidad, ya que la mezcla se expandirá durante el proceso de congelamiento.

4 1/2 tazas mitad crema y mitad leche (half and half)  
2 1/4 tazas de azúcar  
4 1/2 cucharadas de polvo de café instantáneo  
6 tazas de crema

mezcle todos los ingredientes en el bote de mezclar hasta que el azúcar y el polvo de café instantáneo son completamente disueltos. Siga las instrucciones de la sección "Para Hacer Helado", de las **Páginas 4 a la 6**. Solo llene el bote hasta 2/3 de su capacidad, ya que la mezcla se expandirá durante el proceso de congelamiento.

### Helado de Café

- 4 1/2 tazas mitad crema y mitad leche (half and half)
- 2 1/4 tazas de azúcar
- 4 1/2 cucharadas de polvo de café instantáneo
- 6 tazas de crema

mezcle la mezcla en el bote (garrafa) de mezclar y siga las instrucciones de la sección "Para Hacer Helado", de las **Páginas 4 a la 6**. Solo llene el bote hasta 2/3 de su capacidad, ya que la mezcla se expandirá durante el proceso de congelamiento.

mezcle el azúcar, la maicena y la sal en una cacerola grande. A fuego

hasta que la mezcla comience a hervir. Muy lentamente, revolviendo constantemente, agregue lentamente la leche, revolviendo constantemente hasta que la mezcla comience a hervir. Muy lentamente, añada los huevos batidos y continúe revolviendo. Reduzca el fuego y cocine la

mezcla hasta que espese ligeramente. Reduzca el fuego y agregue poco a poco la vainilla, la 1 2/3 tazas de mitad crema y mitad leche y la doble crema. Vacíela en un tazón grande de vidrio, tapelo y

refrigere de 2 a 4 horas o hasta que la mezcla se haya enfriado.

Vacie la mezcla en el bote (garrafa) de mezclar y siga las instrucciones de la sección "Para Hacer Helado", de las **Páginas 4 a la 6**. Solo llene el bote hasta 2/3 de su capacidad, ya que la mezcla se expandirá durante el proceso de congelamiento.

## Rocky Road Ice Cream

- 1 3/4 cups granulated sugar
- 1/2 tsp Salt
- 2 cups milk
- 6 squares semi-sweet chocolate
- 2 cups half and half
- 6 cups whipping cream
- 1 Tbsp vanilla extract
- 2 cups mini marshmallows
- 1 1/2 cups chocolate chips
- 1 cup chopped pecans

Mix the milk and chocolate in a large saucepan. Over medium heat, stir until the chocolate is completely melted. Remove from heat and slowly add sugar and salt, mixing well, until dissolved. Stir in the remaining ingredients except the marshmallows, pecans and chocolate chips, then cover and refrigerate for about 30 minutes or until mixture has chilled. Pour mixture into the mixing canister and follow directions in the "To Make Ice Cream" section, **pages 4-6**. Do not fill the mixing canister more than 2/3 full, as the mixture will expand during freezing. Add marshmallows, pecans and chocolate chips after the ice cream has finished churning and stir in evenly.

## Cherries and Chocolate Ice Cream

- 3/4 cup chocolate shavings
- 3/4 cup fresh cherries, pitted and halved
- 6 large eggs
- 2 1/4 cups sugar
- 6 cups heavy cream
- 3 cups milk

Place the cherries and the chocolate shavings in separate bowls. Cover and chill until cold. Whisk the eggs in a mixing bowl until light and fluffy, 1 to 2 minutes. Slowly mix in sugar, whisking until completely blended. Slowly add cream and milk; whisk until blended. Pour mixture into mixing canister and follow directions in the "To Make Ice Cream" section, **pages 4-6**. Do not fill the mixing canister more than 2/3 full, as the mixture will expand during freezing.

## Hielado de Camino Empedrado

#### Helado de Pasta de Galleta (Cookie Dough)

Helado de Manteca de Cacahuate y Pedacitos de Chocolate (Chocolate Chips)

Refrigeré el pasta de galleta y el chocolate hasta que se hayan enfriado. Bata los huevos hasta que sean muy ligeros (1 o 2 minutos). Viaya agregando poco a poco y alternadamente el azúcar hasta que esté completamente mezclado. Agregue lentamente la crema y la leche y bata hasta que estén mezclados. Vacíela en el bote de mezclar y siga las instrucciones de la sección "Para Hacer Helado", de las páginas 4 a la 6. Solo llene el bote hasta 2/3 de su capacidad, ya que la mezcla se expandirá durante el proceso de congelamiento. Despues de mezclar el helado, desmigaje la pasta de galleta y mezcle en el helado. Coloque la mezcla en el congelador hasta que esté firme.

- 1 taza de pasta de galleta
- 1 taza de pedacitos de chocolate
- 1 huevos grandes
- 2 1/4 tazas de azúcar
- 3 tazas de leche

## RECIPES

# Cookie Dough Ice Cream

- 1 cup chocolate chip cookie dough, crumbled into small pieces  
1 cup mini chocolate chips (optional)  
6 large eggs  
2 1/4 cups sugar  
6 cups heavy cream  
3 cups milk

Place the cookie dough and the chocolate chips in separate bowls. Cover and chill until cold. Whisk the eggs in a mixing bowl 1-2 minutes, until light and fluffy. Slowly mix in sugar, whisking until completely blended. Slowly add cream and milk and whisk until blended. Pour mixture into mixing canister and follow directions in the “*To Make Ice Cream*” section, **pages 4-6**. Do not fill the mixing canister more than 2/3 full, as the mixture will expand during freezing. When the mixture has finished churning, add cookie dough and chocolate chips (optional) and stir in evenly.

## Peanut Butter Chocolate Chip Ice Cream

- 2 2/3 cups granulated sugar  
2 Tbsp cornstarch  
1/2 tsp salt  
1 1/2 tsp vanilla  
6 cups milk  
4 eggs, beaten  
2 cups heavy cream  
1 1/3 cups half and half  
1 1/2 cups chocolate chips  
1 cup peanut butter or 1 cup peanut butter chips, melted

Mix the sugar, cornstarch and salt in a large saucepan. Over medium heat, slowly stir in the milk, stirring constantly. Very slowly, add the beaten eggs and continue to stir. Reduce heat to low and cook until mixture thickens slightly. Slowly stir in peanut butter and whisk until all peanut butter is combined and mixture is smooth. Slowly add vanilla, half and half and heavy cream. Pour into a large glass bowl and refrigerate for 2-4 hours or until mixture has chilled. Pour mixture into the mixing canister and follow directions in the "*To Make Ice Cream*" section, **pages 4-6**. Do not fill the mixing canister more than 2/3 full, as the mixture will expand during freezing. Stir in chocolate chips once ice cream is finished churning and stir evenly.

## LIMITED WARRANTY

Aroma Housewares Company warrants this product free from defects in material and workmanship for one year from provable date of purchase in the continental United States.

Within this warranty period, Aroma Housewares Company will repair or replace, at its option, defective parts at no charge, provided the product is returned, freight prepaid with proof of purchase and U.S. \$18.00 for shipping and handling charges payable to Aroma Housewares Company. Before returning an item, please call the toll free number below for a return authorization number. Allow 2-4 weeks for return shipping.

This warranty does not cover improper installation, misuse, abuse or neglect on the part of the owner. Warranty is also invalid in any case that the product is taken apart or serviced by an unauthorized service station.

This warranty gives you specific legal rights, which may vary from state to state and do not cover areas outside the United States.

**AROMA HOUSEWARES COMPANY**  
 6469 Flanders Drive  
 San Diego, California 92121  
 1-800-276-6286  
 M-F, 8:30 AM - 5:00 PM, Pacific Time  
 Website: [www.aromaco.com](http://www.aromaco.com)

Aroma Housewares Company garantiza que este producto no tenga defectos en sus materiales y fabricación durante un periodo de un año a partir de la fecha comprada de compra dentro de la parte de Estados Unidos.

Dentro de este periodo de garantía, Aroma Housewares Company pagará los gastos de envío y manejo a favor de Aroma Housewares para reparar o reemplazar, a su opción, las partes defectuosas sin ningún costo, siempre y cuando el producto sea devuelto, con el flete prepago, con comprobación de compra y \$18.00 dólares para cargos de envío y manejo a favor de Aroma Housewares.

Compañy. Antes de devolver un producto, sirvase llamar al número telefónico gratuito que está más abajo para obtener un número de autorización de devolución. Espere entre 2-4 semanas para recibir el paquete de devolución. Dentro de este periodo de garantía, Aroma Housewares Company no cubre la instalación incorrecta, el uso indebidamente, negligencia por parte del usuario. La garantía también es inválida en caso de que el aparato sea desarmado o se le dé mantenimiento en un centro de servicio no autorizado.

Esta garantía le da derechos legales específicos los cuales podrán variar de un estado a otro y no cubre áreas fuera de los Estados Unidos.

**AROMA HOUSEWARES COMPANY**  
 6469 Flanders Drive  
 San Diego, California 92121  
 1-800-276-6286  
 L-V, 8:30 AM - 5:00 PM, Tiempo del Pacífico  
 Sitio Web: [www.aromaco.com](http://www.aromaco.com)

## GARANTÍA LIMITADA